

<u>Instructions for using AC electric vehicle charging</u> <u>stations of EPBiH – Schneider Electric 2x22 kW brand</u>

Charging

- 1. Swipe the RFID card* over the sensor on the front side of the charging station until you get a sound signal.
- 2. On the charging station you have two different buttons: START (green) and STOP (red). Push the START button and wait for the sound of opening the connector shutter.
- 3. i 4. Lift the shutter and connect the cable into the charging station and the vehicle. On displays of the charging station and the vehicle you will get an information on charging time.
- 5. Charging cable will be locked (can not be unplugged) during the charging process, until you swipe again the RFID card over the sensor at the front side of the charging station.

Disconnecting from the network

- 1. To stop the charging process, swipe the RFID card over the sensor.
- 2. Push the button STOP (red).
- 3. Lift the shutter and disconnect the cable from the charging station.
- 4. Disconnect the cable from the vehicle.

Contact phone: 033 751 937